

### Error Code 29

Explanation: Heat Exchanger outlet temperature is too low. At a minimum check the following:

1. Clean air inlet filter.
2. Check for buildup on the heat exchanger fins.
3. Set thermostat to 120 degrees. Verify heat exchanger temperature with water at hot outlet.

