

### Error Code 33

Explanation: Hot Water Outlet Thermistor has malfunctioned. At a minimum check the following if you get Error Codes 31, 32, 33, & 34:

1. Check for scale build up on the inlet filter screen. This scale build up could also happen inside the machine. Scale build up on all thermistors will cause them to be inaccurate.
2. IF maintenance mode shows 32 degrees as the temperature, then the thermistor is not making connection. (Possibly unplugged, possibly broken wire).
3. IF maintenance mode shows 199 degrees the thermistor has a direct short.

