

Error Code 52

Explanation: Proportional Gas Flow Regulator (P.G.F.R.) Valve fault. Check gas inlet solenoid valve wiring harnesses for loose or damage terminals; and connections to the circuit board are tight.

